

RouterBOARD Groove

User's Manual

The RouterBOARD **Groove** comes preinstalled in an outdoor enclosure, with built-in wireless, an N-Male antenna connector, and one 10/100 Ethernet connector which supports MDI-X auto detection. The device is packaged with a 24V power adapter, a PoE injector and two mounting loops. Groove is available in four versions: CPE and AP models of both 2GHz and 5GHz variants.



Copyright and Warranty Information

Copyright and Trademarks. Copyright MikroTik SIA. This manual contains information protected by copyright law. No part of it may be reproduced or transmitted in any form without prior written permission from the copyright holder. RouterBOARD, RouterOS, RouterBOOT and MikroTik are trademarks of MikroTik SIA. All trademarks and registered trademarks appearing in this manual are the property of their respective holders.

Hardware. MikroTik warrants all RouterBOARD series equipment for the term of fifteen (15) months from the shipping date to be free of defects in materials and workmanship under normal use and service, except in case of damage caused by mechanical, electrical or other accidental or intended damages caused by improper use or due to wind, rain, fire or other acts of nature.

To return failed units to MikroTik, you must perform the following RMA (Return Merchandise Authorization) procedure. Follow the instructions below to save time, efforts, avoid costs, and improve the speed of the RMA process.

1. If you have purchased your product from a MikroTik Reseller, please contact the Reseller company regarding all warranty and repair issues, the following instructions apply **ONLY** if you purchased your equipment directly from MikroTik in Latvia.
2. We do not offer repairs for products that are not covered by warranty. Exceptions can be made for RB1000, RB1100, RB1200.
3. Out-of-warranty devices and devices not covered by warranty sent to MikroTik will be returned to the sender at sender's cost.

RMA Instructions are located on our webpage here: <http://rma.mikrotik.com>

Manual. This manual is provided “as is” without a warranty of any kind, expressed or implied, including, but not limited to, the implied warranty of merchantability and fitness for a particular purpose. The manufacturer has made every effort to ensure the accuracy of the contents of this manual; however, it is possible that it may contain technical inaccuracies, typographical or other errors. No liability is assumed for any inaccuracy found in this publication, nor for direct or indirect, incidental, consequential or other damages that may result from such an inaccuracy, including, but not limited to, loss of data or profits. Please report any inaccuracies found to support@mikrotik.com

USER'S MANUAL	1
COPYRIGHT AND WARRANTY INFORMATION	1
SPECIFICATIONS	3
WIRELESS SPECIFICATIONS	3
HARDWARE GUIDE	3
INPUT/OUTPUT PORTS	3
<i>Ethernet ports</i>	3
LEDs	4
USER'S GUIDE	4
MOUNTING	4
FIRST USE.....	4
GROUNDING.....	4
POWERING	4
EXPANSION SLOTS AND PORTS	5
BUTTONS AND JUMPERS	5
BOOTING OPTIONS.....	5
<i>Onboard NAND Storage Device</i>	5
<i>Booting from network</i>	5
<i>Operating System Support</i>	6
ROUTEROS FUNCTIONS	6
HEALTH MONITOR	6
FIRMWARE INFORMATION	6
FIRMWARE SETTINGS	6
APPENDIX	7
ETHERNET CABLES	7
SYSTEM BOARD VIEW AND LAYOUT.....	7

Specifications

	2Hn	A-2Hn	5Hn	A-5Hn
CPU	AR7241 400MHz	AR7241 400MHz	AR7241 400MHz	AR7241 400MHz
Memory	32MB	64MB	32MB	64MB
Data storage	NAND chip	NAND chip	NAND chip	NAND chip
Ethernet	One 10/100 Mbit/s Ethernet port supporting Auto-MDI/X	One 10/100 Mbit/s Ethernet port supporting Auto-MDI/X	One 10/100 Mbit/s Ethernet port supporting Auto-MDI/X	One 10/100 Mbit/s Ethernet port supporting Auto-MDI/X
Wireless	Built-in 2GHz 802.11b/g/n 1x1 MIMO, N-male connector, CPE mode	Built-in 2GHz 802.11b/g/n 1x1 MIMO, N-male connector, CPE or AP mode	Built-in 5GHz 802.11a/n 1x1 MIMO, N-male connector, CPE mode	Built-in 5GHz 802.11a/n 1x1 MIMO, N-male connector, CPE or AP mode
Extras	Reset switch, Beeper, Voltage monitor, Temperature monitor	Reset switch, Beeper, Voltage monitor, Temperature monitor	Reset switch, Beeper, Voltage monitor, Temperature monitor	Reset switch, Beeper, Voltage monitor, Temperature monitor
LEDs	5 wireless signal LEDs, ethernet activity LED (configurable)	5 wireless signal LEDs, ethernet activity LED (configurable)	5 wireless signal LEDs, ethernet activity LED (configurable)	5 wireless signal LEDs, ethernet activity LED (configurable)
Power	Passive 9-30V PoE only. 16KV ESD protection on RF port	Passive 9-30V PoE only. 16KV ESD protection on RF port	Passive 9-30V PoE only. 16KV ESD protection on RF port	Passive 9-30V PoE only. 16KV ESD protection on RF port
Dimensions	177x44x44mm, 193g. Must be mounted with ethernet pointing down	177x44x44mm, 193g. Must be mounted with ethernet pointing down	177x44x44mm, 193g. Must be mounted with ethernet pointing down	177x44x44mm, 193g. Must be mounted with ethernet pointing down
Operational Temperature	-30C to +70C	-30C to +70C	-30C to +70C	-30C to +70C
Power consumption	Up to 0,19A at 24V (4.56W)	Up to 0,19A at 24V (4.56W)	Up to 0,19A at 24V (4.56W)	Up to 0,19A at 24V (4.56W)
RouterOS	V5, License L3	V5, License L4	V5, License L3	V5, License L4
Package contains	Groove unit, mounting loops, PoE injector, 24V power adapter			

Wireless specifications

	Groove 2Hn / A-2Hn	Groove 5Hn / A-5Hn
RX sensitivity	802.11b/g: -92 dBm @ 6Mbps to -75 dBm @ 54 Mbps 802.11n: -92 dBm @ MCS0 to -71 dBm @ MCS7 40MHz	802.11a: -93 dBm @ 6Mbps to -77 dBm @ 54 Mbps 802.11n: -93 dBm @ MCS0 to -71 dBm @ MCS7
TX power	802.11b/g: 27dBm @ 6Mbps to 24dBm @ 54 Mbps 802.11n: 27dBm @ MCS0 to 20dBm @ MCS7	802.11a: 23dBm @ 6Mbps to 19dBm @ 54 Mbps 802.11n: 22dBm @ MCS0 to 15dBm @ MCS7
Modulations	OFDM: BPSK, QPSK, 16 QAM, 64QAM DSSS: DBPSK, DQPSK, CCK	OFDM: BPSK, QPSK, 16 QAM, 64QAM DSSS: DBPSK, DQPSK, CCK

Hardware Guide

Input/Output Ports

Ethernet ports

Device is compatible with passive (non-standard) Power over Ethernet. The board accepts voltage input from 8 to 30 V DC. It is suggested to use higher voltages for power over long cables because of better efficiency (less power is lost in the cable itself and power supply is more efficient).

See **Connector Index** for pinout of the standard cable required for PoE. All cables made to EIA/TIA 568A/B cable specifications will work correctly with PoE. Note that this port supports automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other devices.

LEDs

Ethernet LED is on when the board is powered. It is the first LED from the bottom.

There are five LEDs which show wireless signal strength:

- 1 - on, if wireless client is connected to AP (usually $\geq -89\text{dBm}$)
- 2 - on, if signal strength $\geq -82\text{dBm}$ (bad signal)
- 3 - on, if signal strength $\geq -75\text{dBm}$
- 4 - on, if signal strength $\geq -68\text{dBm}$
- 5 - on, if signal strength $\geq -61\text{dBm}$ (good signal = all LEDs on)

It is possible to disable this function (turn all these LEDs off or re-assign them) via software configuration.

User's Guide

Mounting

The Groove is to be mounted **vertically**, so that the Ethernet cable points **downwards**.

If you wish to tighten the Groove to a pole, you can do it with the provided mounting loops. The Groove comes bundled with two mounting loops - guide the loops around the Groove through the provided edge markings, and around the pole where it will be mounted. You should avoid connecting a loose Ethernet cable to the Ethernet port, secure the cable to a wall or the pole, so that the cable weight is not pulling the port. It is recommended to secure the Ethernet cable less than 2m from the Groove device. This is to ensure that the cable doesn't damage the port by its weight, or doesn't fall out.

First use

The device is assembled and ready for deployment. You must mount the antenna on the built-in N-male connector before turning on the device via PoE!

1. Mount an antenna on the built in N connector. Any antenna can be used, which works in the frequencies supported by the chosen Groove model
2. Plug the supplied PSU into a power socket, and connect it to the supplied PoE injector
3. Connect the "DATA" end of the injector to a switch or any other device, and the other end (which says "DATA+POWER") to an Ethernet cable leading to the Groove device
4. Open **192.168.88.1** in your web browser to start Quickset and configure the Groove. You might need to adjust your PC IP address to connect to this IP. For advanced configuration guides, see: <http://wiki.mikrotik.com/wiki/Category:Manual>

In case IP connection is not available, *Winbox* can be used to connect to the MAC address of the device. More information here: http://wiki.mikrotik.com/wiki/First_time_startup

Grounding

It is recommended using a FTP (foil screened twisted pair) cable – in this case, one end of the cable would be plugged into the SXT, the other end of the cable will be connected to the buildings grounding installation. If possible, also connect a grounding wire to the provided grounding connection behind the SXT case door.

Powering

Power over Ethernet (PoE) on the Ethernet port: 8-30V DC (12-28 V suggested) non-standard PoE powering support. 24V PSU is supplied with the device

RouterBOARD Groove series devices are compatible with non-standard (passive) Power over Ethernet injectors (except power over data lines) and accept powering over up to 100m (330 ft) long Ethernet cable connected to the Ethernet port (**J4**). The board **does not** work with IEEE802.3af compliant 48V power injectors.

Expansion Slots and Ports

1. Built in 2GHz 802.11b/g wireless, 1x1 MIMO, station mode
2. One 10/100 Ethernet port, supporting automatic cross/straight cable correction (Auto MDI/X), so you can use either straight or cross-over cable for connecting to other network devices. The Ethernet port accepts 8-30V DC powering from a passive PoE injector.

Buttons and Jumpers

- RouterOS reset jumper hole (no direct access, board has removed from case) – resets RouterOS software to defaults. Must short circuit the metallic sides of the hole (with a screwdriver, for example) and boot the device. Hold screwdriver in place until RouterOS configuration is cleared.
- RouterBOOT reset button (access through the plastic door) has two functions:
 - Hold this button during boot time until LED light starts flashing, release the button to **reset RouterOS configuration** (same result as with reset hole)
 - Hold this button during boot time longer, until LED turns off, then release it to make the device **look for Netinstall servers**.

Booting options

In case you wish to boot the device from network, for example to use MikroTik Netinstall, hold the RESET button of the device when starting it until the LED light turns off, and Groove will start to look for Netinstall servers.

Onboard NAND Storage Device

The RouterBOARD may be started from the onboard NAND storage chip. As there is no partition table on the device, the boot loader assumes the first 4MiB form a YAFFS filesystem, and executes the file called "kernel" stored in the root directory on that partition. It is possible to partition the rest of the medium by patching the kernel source.

Booting from network

Network boot works similarly to PXE or EtherBoot protocol, and allows you to the device from an executable image stored on a TFTP server. It uses BOOTP or DHCP (configurable in boot loader) protocol to get a valid IP address, and TFTP protocol to download an executable (ELF) kernel image combined with the initial RAM disk (inserted as an ELF section) to boot from (the TFTP server's IP address and the image name must be sent by the BOOTP/DHCP server).

To boot the RouterBOARD computer from Ethernet network you need the following:

- An ELF kernel image for the loader to boot from (you can embed the kernel parameters and initrd image as ELF sections called *kernparm* and *initrd* respectively)
- A TFTP server which to download the image from
- A BOOTP/DHCP server (may be installed on the same machine as the TFTP server) to give an IP address, TFTP server address and boot image name

See the **Error! Reference source not found.** section on how to configure loader to boot from network.

Note that you must connect the RouterBOARD you want to boot, and the BOOTP/DHCP and TFTP servers to the same broadcast domain (i.e., there must not be any routers between them).

Operating System Support

MikroTik RouterOS starting from version v5 is fully compatible with RouterBOARD Groove series devices. If your device is preinstalled with an earlier RouterOS release, please upgrade RouterOS to v5.14 or newer.

RouterOS functions

The default OS of RouterBOARD devices is RouterOS, when the *routerboard.npk* package is installed, RouterOS can configure some RouterBOARD hardware settings without the need to enter RouterBOOT menu through the serial console.

Health monitor

This menu shows the current voltage and temperature status. There are two temperature sensors on the device:

```
[admin@MikroTik] > system health print
    voltage: 12.4V
    temperature: 40C
[admin@MikroTik] >
```

Firmware information

This menu displays RouterBOARD model number, serial number, the current boot loader version and the version available in the current software packages installed.

```
[admin@MikroTik] > system routerboard print
    routerboard: yes
        model: Groove A-5Hn
    serial-number: 2B9F015A92DE
    current-firmware: 2.38
    upgrade-firmware:2.38
[admin@MikroTik] >
```

The firmware version can be upgraded from **RouterOS** by using **"/system routerboard upgrade"** command.

Firmware Settings

Boot loader settings are also accessible through this menu.



```
[admin@MikroTik] > system routerboard settings print
    boot-device: nand-if-fail-then-ethernet
    boot-protocol: bootp
    force-backup-booter: no
[admin@MikroTik] >
```

Appendix

Ethernet Cables

RJ45 Pin	Color	Function (100Mbit)	Function (1Gbit)	RJ45 pin for Straight cable (MDI, EIA/TIA568A)	RJ45 pin for Crossover cable (MDI-X, EIA/TIA568B)
1	Green	TX+ Data	Data A+	1	3
2	Green/White	TX- Data	Data A-	2	6
3	Orange	RX+ Data	Data B+	3	1
4	Blue	-	Data C+	4	4
5	Blue/White	-	Data C-	5	5
6	Orange/White	RX- Data	Data B-	6	2
7	Brown	-	Data D+	7	7
8	Brown/White	-	Data D-	8	8

System Board View and Layout



You can download the board dimensions and case design files (PDF and DXF) from www.routerboard.com