

# Banana Pi Expansion Module User Manual

## **BPI-I2C**

### **Maximum Power at Minimum Size**

[www.banana-pi.com](http://www.banana-pi.com)



## Directory

Directory .....	2
1 : Product Specification : .....	7
2 : Produce Overview : .....	8
3 : Produce Features : .....	8
4 : Port : .....	8
5 : Product Parameters : .....	8
6 : Typical Application : .....	8
7 : How to use : .....	9
7.1: Schematic diagram: .....	10



2

## **Shenzhen SINOVOIP CO., LIMITED Copyright Statement :**

The document only describes the information about the product. However, it cannot guarantee the product function and performance. If the document content or the product feature and technical specifications included in the document are changed, it will be notified further.

Content in the document might be outdated. Our cooperation cannot promise to update this information.

Some information in the document might be disabled in your local area, including product and service. You can consult with the contact and agency in your local area.

Copyright in the document belongs to Shenzhen SINOVOIP CO., LIMITED. Users can only use this content after they or she get authorization from our company or other obligee. However, users cannot copy, paraphrase, or create similar devices or products.

The document's final right to interpret and document use belongs to Shenzhen SINOVOIP CO., LIMITED.

More information:

Get more product and support. Please contact Shenzhen SINOVOIP CO., LIMITED ([www.banana-pi.com](http://www.banana-pi.com))

**Attention:**

3

---

## Banana Pi I2C Module User Manual

Due to technical requirements components, please do not hand directly connected

Touch. Core board and development system contains static-sensitive devices. Quiet Electrical charge easily accumulate in the human body and the device can not detect possible Damage to equipment, it is recommended to take anti-static measures, it is recommended not to hand. Touch, stored in anti-static effect devices.



## **Banana Pi Expand Module Serial :**

### **Infinity cascade IO expand module :**

This module is designed specifically for the Banana Pi IO expansion modules. The module expand 32 IO, Multiple modules can cascade, infinity cascade, infinity GPIO.

### **I2C GPIO expand module :**

This module is designed specifically for the Banana Pi IO expansion modules. The Module use I2C bus to connect to Banana Pi. The module expand 8 Bidirectional GPIO and wit isolation protection function which can effectively excessive external voltage. There are 8 I2C address, you can choose one of them through setup the jumper. Multiple modules can cascade and maximum cascade 8 modules!

### **Prototype development module :**

The Prototype development module is designed specifically for the Banana Pi. The module suitable enthusiasts and user can weld peripheral to the module ; The module expand some amphenol connector and some SMT, so the user can finish prototype test easily.

### **Berryclip expand module :**

The BerryClip module is designed specifically for learning how to use the GPIO of Banana Pi. There are 6 multiple color LED, 1 button and 1 Buzzer on the module.

### **Berryclip(DIY) expand module :**

The module is not the end product, you need weld them by yourself. The function of the module is the same as BerryClip module.

### **UNO compatibility module :**

The module makes Banana Pi compatible with Arduino Uno and many Arduino Shields. The module's GPIO is the same as Arduino Uno and you can choose the voltage of GPIO between 5V or 3V through setup jumper.

### **T Electric level convert module :**

---

## Banana Pi I2C Module User Manual

The module expand the GPIO of Banana Pi to breadboard. It convert 3.3V electric to 5V electric level, then the Banana Pi can connect many 5V electric level peripheral.

### **IO extraction module :**

The module expand all of GPIO of Banana Pi to breadboard.

### **RTC expand module :**

The RTC module is specifically designed for Banana Pi. There is a 0.2uF SuperCapacitor on the board to keep the real time for a long time after the Banana Pi has power off.

### **AD/DA expand module :**

The AD/DA module is specifically designed for Banana Pi. There is 8bit high resolution DAC and ADC on one chip.


### **I2C electric level conversion expand module :**

The I2C electric level conversion module is specifically designed for Banana Pi. The module convert the 3.3V of I2C electric level to 5V level or convert 5V to 3.3V.

### **I2C electric level conversion expand module :**

The Serial Por module is specifically designed for Banana Pi. The module use Maxim MAX232 chip and DB9 port. So the user don't need to connect Dupont Line and that avoid wrong wiring. User can use this module to debug Banana Pi easily.

**1 : Product Specification :**



## **2 : Produce Overview :**

The I2C electric level conversion module is specifically designed for Banana Pi. The module convert the 3.3V of I2C electric level to 5V level or convert 5V to 3.3V. The module made by NMOSFET, it makes the module have fast feedback and the low power. There is an pull-up resistor to solve the open-drain output level is not stable.

## **3 : Produce Features :**

- Strong anti-interference ability
- Pull-up resistor on board
- 1.8 V, 2.4 V and 3 V, 5 V voltage conversion to each other

## **4 : Port :**

- 1X6 Header

## **5 : Product Parameters :**


- Working voltage: 1.8V-5.5V
- 4 conversion channel

## **6 : Typical Application :**

- Interface electric level conversion



**7 : How to use :**



As show in picture, the left Header is the output or input port of lower electric level;  
The right Header is the output or input port of higher electric level.

### 7.1: Schematic diagram:

